

FUSION®

USER / INSTALLATION MANUAL

MARINE WIRED REMOTE CONTROL

MS-WR600



FUSION®

www.fusionelectronics.com

FUSION Electronics New Zealand Ph: +64 9 369 2997
FUSION Electronics Australia Ph: +61 1300 736 012
FUSION Electronics Europe Ph: +44 1268 889580
FUSION Electronics USA Ph: +1 623 580 9000

PUBLISHED BY FUSION ELECTRONICS LIMITED:
©Copyright 2008 by FUSION Electronics Limited. All rights reserved.
Specifications and design are subject to change without notice.



YOU CAN HELP PROTECT THE ENVIRONMENT!
Please remember to respect the local regulations: Hand in the non-working electrical equipment to an appropriate waste disposal center.

COMPATIBLE WITH MS-CD600, MS-AV600 AND MS-IP600

BUTTON DESCRIPTION



POWER
Press to turn the unit ON/OFF.



SOURCE
Press to select the desired source.
Radio (FM-AM-SIRIUS) - DVD/CD/MP3 - iPod - AUX (SIRIUS - USA only)



MUTE
Short Press
Press to Mute/Un-Mute sound in all zones.
Press and Hold
To enter configuration menu.



MENU
Press to enter menu system. Press to return to previous screen.



PLAY/PAUSE
Play/Pause track in DVD/CD/MP3 and iPod mode.



ROTARY ENCODER
Turn
To adjust volume, move up or down a menu structure, or adjust a specific setting item.
Press
To select a highlighted option, confirm a setting.



BACK/PREVIOUS
Short Press
DVD/CD/MP3/iPod - Select the previous track.
AM/FM/Sirius - Start tuning down the frequency spectrum. (Auto/Manual tuning mode) or previous preset (Preset mode).



FORWARD/NEXT
Short Press
DVD/CD/MP3/iPod - Select the next track.
AM/FM/Sirius - Start tuning up the frequency spectrum. (Auto/Manual tuning mode) or next preset (Preset mode).
Press and Hold
DVD/CD/MP3/iPod - Fast forward the current track.

OPERATION

ASSIGNING THE REMOTE TO A ZONE

Press and hold the 'Mute' button for 5-6 seconds. Select 'Assign Zone'. Select zone to allocate remote too. (Zone 1, Zone 2, Zone 3, Zone 123). Press the 'Menu' button to exit.

SUB LIMIT

Press the 'Menu' button and select 'Sub Limit'. Turn the 'Rotary Encoder' to adjust level. Press the 'Menu' button to exit.

ZONE VOLUME

Turn the 'Rotary Encoder' to adjust the volume in the assigned zone.

BACKLIGHT BRIGHTNESS

Press and hold the 'Menu' button while turning the 'Rotary Encoder' to adjust.

Standby Mode

After a period of inactivity the remote enters standby mode, reducing the backlight brightness. (Default) To switch the backlight off in standby mode (Power save), press and hold the 'Mute' button for 5-6 seconds. Select 'Backlight'. Select 'Off'. Press the 'Menu' button to exit.

INSTALLATION

To complete the ultimate marine audio experience, a total of three MS-WR600 Marine Wired Remote Controls can be installed in various locations, creating a flexible zone control solution throughout a vessel. The MS-WR600 is a plug and play device. Connect to the CANbus cable connection on your FUSION Marine Stereo. Please refer to the MS-CD600/MS-AV600/MS-IP600 Marine Stereo manual for further detailed operation instructions.


Option 1: Recommended installation.

Option 2: Requires a Y Splitter Cable (MS-WR600Y, sold separately). Cables from the splitter (*) to each remote must be of equal length to ensure correct operation.



Note: The supplied 'Terminator Plug' must be fixed to the last remote. Failure to do so could effect operation.

Optional Accessory: MS-WR600EXT6 - 6m extension lead.
MS-WR600Y - Y Splitter Cable

OPTION 1



OPTION 2



RECORD YOUR PRODUCT DETAILS HERE:

Model Number

Date Of Purchase

Affix Receipt Here